

Outward Opening Hinged Emergency Egress System

The Escape Security Screens Outward Opening Hinged Emergency Egress System is designed to provide an escape route in the event of a fire or emergency situation in domestic or commercial buildings.

Fixed bars or barriers are a major safety risk and should not be used to cover all windows in a domestic environment. In our attempts to maximise security we often compromise the safety of the building inhabitants in the case of fire or emergency.

- Escape Security Screens provide simple, keyless, one handed unlocking of the window security screen from the inside.
- Once unlocked, the security screen then hinges open to allow a path of escape.
- An additional benefit of fitting an Escape Security Screens to your window is the ease of cleaning and in the case of accidental breakage, replacement of the window glass.
- All Escape Security Screens have been tested to Australian Standards AS5039-2008 so you can be assured that when choosing Escape Security Screens, you are choosing the best option for your safety and security.

The Escape Security Screens system offers the perfect answer to your security and safety. Easy to operate, allowing you to exit the building freely in case of an emergency.

Multiple Infill Options



Alspec **Alu-Grille** offers a 7mm strand thickness that will improve the security of your home, meeting all the requirements of the Australian Security Door Standard AS5039.



Alternatively, if added privacy is required, Alu-Gard Perforated Aluminium Mesh provides reduced visibility into your home while also providing full security.



For an ultimate privacy, **Vision-Gard** not only secure your home but also provide a degree of privacy from people outside your home looking in.

Two Step Emergency Escape System

During an emergency situation, you don't have time to be fumbling around with complicated latches and locks. With the Escape Security Screens system, a squeeze and push is all that's needed to get you and your family out safely.

Step 1 - Squeeze

Locate the spring loaded lock handle running down the length of the sash. Insert your fingers and squeeze handle towards the external frame.



Step 2 - Push

With your other hand, push firmly against the escape sash. The sash should freely swing outward to allow passage.



